

**SISTAR s.a.s.**

Via Laboratori Autobianchi 1  
Polo Tecnologico Brianza – Edificio 14  
20832 Desio (MB) Italy  
Tel. (+39) 0362-367350 - Fax (+39) 0362-367352  
[www.sistar.it](http://www.sistar.it) – e-mail: [info@sistar.it](mailto:info@sistar.it)

**INFORMATIVE NOTE**

<b>Denomination: ORANGE GRIP</b>	
<b>Date: 10/10/2018</b>	
<b>Rev: 00</b>	

**DESCRIPTION:** ■ Powder -free non sterile disposable glove ■ **Material:** nitrile ■ **Form:** ambidextrous; five fingers, rolled edge ■ **Color:** orange ■ **Finishing:** glove externally embossed ■ **Packaging:** 50 pieces/box; 10 boxes/carton ■ **ISO 2859:** AQL 1,5 (level G1)

**CONFORMITY AND PERFORMANCE**

Personal Protection Equipment cat III

0465 A.N.C.I. Servizi srl - Sezione CIMAC c/so G. Brodolini, 19 27029 Vigevano (PV)



Reg UE 2016/425 - EN 420:2003 + A1 2009, EN 374-1:2016 TIPO B, EN 374-2:2014, EN 374-4:2013, EN 374-5:2016

		EN 374-1: 2016 TYPE B	EN 374-4:2013	SIZES			
		Performance level	Passage time	% degradation	Cod./Size	Length mm	Width mm
Sulphuric acid 96%		2	>30'	100%	553.2755.M (8)	250	90-99
Sodium hydroxide 40%		2	>30'	11.9%			
Diethylamine		2	>30'	78.1%			
Thickness mm	Palm (+/- 0.03)	0.12		553.2755.L (9)	260	100-109	
				553.2755.XL (10)	270	110-119	
				553.2755.XX L (11)	280	120-129	

**ADVICE ON USE**

Multi-purpose glove to protect the hand and/or product handled, can also be used for general purposes ■ The glove is suitable for contact with pure chemicals for less than the permeation time indicated in the chemical resistance table ■ The results are obtained under laboratory conditions and may not reflect the actual duration in the workplace



**SISTAR s.a.s.**

Via Laboratori Autobianchi 1  
Polo Tecnologico Brianza – Edificio 14  
20832 Desio (MB) Italy  
Tel. (+39) 0362-367350 - Fax (+39) 0362-367352  
[www.sistar.it](http://www.sistar.it) – e-mail: [info@sistar.it](mailto:info@sistar.it)

**WARNINGS**

■ READ the Information Note carefully before using the glove ■ Before using the product, try it its actual condition of use ■ The glove is a device subject to wear and tear, so it is recommended to replace it frequently and in all cases where imperfections are visible. ■ Wear gloves with clean, dry hands ■ In rare cases, transient skin reactions and hypersensitivity reactions may occur ■ In case of a reaction discontinue use

**STORAGE AND DISPOSAL**

■ Keep the gloves in the original packaging, in a dry place ■ Do not expose to sunlight or heat sources ■ The expiry date is 3 years from the production date, indicated on the sales packaging, and is valid for properly stored product ■ Gloves must be disposed of according to local regulations